

# **ROWD** **INSTRUCTIONS**





## ***STEP 1***

Connect tow cable to the back using two shackles with sufficient rating for work at hand.

For ROWD sleds without the front tow plate, connect tow cable with shackles with sufficient rating for work at hand.

*NOTE: Sleds equipped with tow plate and hook do not need a cable on the front.*





## ***STEP 2a***

Insert back gate panel into stake pockets and bolt in place. Then insert side panels into stake pockets and pin in corners.

*NOTE: Side panels have location marked on the top corner by pin ear.*





## ***STEP 2b***

Pin corners and secure pins with hitch pin.





## ***STEP 3***

Open two gate panels on one side to access the inside of ROWD.

Install a single bottom row of straw bales on three sides and add filter fabric across the base of the sled and over the row of straw bales.

*NOTE: Filter fabric or Geotech can be used.*





## ***TIP:***

Make sure filter fabric is over the bottom row of straw bales and is tucked into the bottom corners. Leave enough extra filter fabric so that when the inner ring panels are installed, they do not rip the filter fabric.





 **ROWD**

*TUCK FILTER FABRIC OVER BOTTOM ROW OF STRAW BALES*



## ***STEP 4a***

Insert inner ring panels to secure filter material in place.

*NOTE: Inner ring panels set on top of the filter fabric liner.*







## ***STEP 4b***

Pin corners and secure pins with hitch pin.





## ***STEP 5***

Complete bottom row of bales on the side with open gates, folding filter fabric over the top when complete. Close gates.

*NOTE: At this time, the inner and outer rings should be in place with a single row of straw bales around the perimeter, and filter fabric under the inner ring and over the bottom row of bales.*





## ***STEP 6***

Install top row of straw bales above filter fabric and bottom row of bales.

Unit is now ready for a filter bag.





## ***STEP 7***

Put filter bag remover in center of inner ring and lay filter bag on top of filter bag remover.





## ***STEP 8***

Put piping inlet on ROWD and connect hose to filter bag.

*NOTE: Make sure filter bag is securely connected to hose.*





 **ROWD**

*PIPING INLET ON SLED*



 **ROWD**

*FILTER BAG CONNECTED TO HOSE*



 **ROWD**

*HAUL ASSEMBLED ROWD ON A SKID TUCK OR A FLATBED TRAILER*





***READY TO  
DEWATER***





 **ROWD**

# **ROWD**

***ROWDsled.com***

***3314 56th Street, Eau Claire, WI 54703***

***O: (715) 491-1895***